INSTRUCTION MANUAL

5 Light Chandelier
Talo
Home Depot SKU 528-067 (UPC 718212272152)
(Driftwood Finish)



LA-2034E/S/F

Thank you for purchasing this Hampton Bay interior light fixture. This product has been manufactured with the highest standards of safety and quality.

FEATURES:

1. Traditional 5 light Chandelier in Driftwood Finish.

2. Timeless Elegant Design.

3. Easy to assemble and install.

QUESTIONS, PROBLEMS, MISSING PARTS:

Before returning to your local Home Depot, please call our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your SKU (528-067 Driftwood Finish) or UPC (718212272152 Driftwood Finish).

CAUTION:

1. Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

2. CONSULT A QUALIFIED ELECTRICIAN IF YOU HAVE ANY ELECTRICAL QUESTIONS.

3. If you have any non-electrical questions about this fixture, please contact our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your SKU (528-067 Driftwood Finish) or UPC (718212272152 Driftwood Finish).

4. Keep your receipt and these Instructions for Proof of Purchase.

TOOLS REQUIRED FOR ASSEMBLY & INSTALLATION (not included):

Light Bulb
(60 watt maximum)



Chain Pliers



Step Ladder



Wire strippers

Flathead screwdriver



Phillips screwdriver

Electrical tape

Wire cutters

PARTS INCLUDED FOR ASSEMBLY (parts are not to scale):



5 Screw (#3)

5 Rod 1 (#2)

5 Rod 2 (#7)

5 Metal Tube (#4)

1 Bottom Cap (#8)

1 Finial (#9)

ASSEMBLY INSTRUCTIONS:

1. Shut off power at the fuse box or circuit breaker box, if necessary remove old fixture and all mounting hardware from outlet box.
2. Carefully unpack your new fixture and lay out all the parts on a clear area, Take care not to lose any small parts necessary for installation.
3. Secure the Light Cluster Assembly (#1) onto the Fixture Body (#6) and pull the wire until taut.
4. Upside down the fixture, place five pieces Rod 2 (#7) in to each bracket located at bottom of Fixture Body (#6) and connected by Bottom Cap (#8) and secure them using Finial (#9). (Note: Make sure the top end of Rod 2 (#7) be slide into the bracket on bottom of Fixture Body (#6), and the bottom end of Rod 2 (#8) be located into the notch of Bottom Cap (#8), all of Rods are in proper position.)
5. Upside down the fixture again, slot the Rod 1 (#2) with Screw to the Keyhole located at the top of Light Cluster Assembly (#1), then connect the other end of Rod 1(#2) to Fixture Body (#6) and secure with Screw (#3). Do the same with the rest Rod 1(#2).
6. Place the Metal Tube (#4) over the Socket (#5).

ASSEMBLY:


1. Light Cluster Assembly
2. Rod 1
3. Screw
4. Metal Tube
5. Socket
6. Fixture body
7. Rod 2
8. Bottom cap
9. Finial

PARTS INCLUDED FOR INSTALLATION (parts are not to scale):


1 Ground Screw (#15)

3 Wire Connectors (#20)

1 Lock Washer (#18)


2 Outlet Box Screw (#16)

1 Nipple (#14)

1 Ceiling Loop with Chain (#13)

1 Quick Link (#10)

1 Lock Collar (#11)


1 Hex Nut (#19)

1 Canopy (#12)

1 Crossbar (#17)

INSTALLATION INSTRUCTIONS:

1. Thread Nipple (#14) into ceiling Loop (#13) until snug.
2. Thread other end of Nipple with ceiling loop attached into crossbar (#17) until snug.
3. Place Lock Washer (#18) over end of Nipple (#14) protruding through crossbar and thread Hex Nut (#19) onto nipple until tight.
4. Take the crossbar assembly and mount to outlet box (#21) with outlet box screws (#16). Tighten screws securely with screwdriver.
5. By measuring determine correct number of links needed for proper hanging height. Use a pair of pliers to open one end link of the chain and discard un-wanted chain. (Don't disregard the Quick Link linked at the end of Chain.)
6. Slip Canopy (#12) and Lock Collar (#11) through over the Ceiling Loop with Chain (#13), then connect the other end of Ceiling Loop with Chain (#13) to Fixture Loop by using Quick Link (#10).
7. Lace the fixture's wires through the chain links and pull until taut. Feed the fixture wires through the Lock Collar, Canopy, Ceiling Loop and Nipple and pull until taut.
8. Connect the ribbed wire from the fixture to the Neutral wire from the outlet box (#21) and the smooth wire from the fixture to the hot wire from the outlet box (#21). Cover the two wire connections using the two provided wire connectors (#20). Wrap the two wire connections with electrical tape for a more secure connection. If your outlet box has a ground wire (green or bare copper), connect fixture's ground wire to it using the wire connector (#20). Otherwise connect the copper ground from the fixture to Ground screw (#15) on the Crossbar (#17). *Note: If you have electrical questions, consult your local electrical code for approved grounding methods.*
9. Tuck these wire connections neatly into the ceiling junction box and then raise the canopy all the way to the ceiling. Raise the Lock Collar and thread onto Ceiling Loop protruding through Canopy.
10. Install the proper light bulbs (not include) for your fixture. (DO NOT EXCEED THE SPECIFIED WATTAGE!).
11. Installation is complete. Turn on the power at the circuit breaker or fuse box. Turn the light switch on to activate the fixture.

INSTALLATION:



TROUBLESHOOTING:

	Possible Cause	Corrective Action
Bulb will not light.	1. Bulb is burned out.	1. Replace light bulb.
	2. Power is off.	2. Make sure power supply is on.
	3. Faulty wire connection.	3. Check wiring.
	4. Faulty switch.	4. Test or replace switch.
Fuse blows or circuit breaker trips when light is turned on.	Crossed wires or power wire is grounding out.	Check wire connections.

PRODUCT MAINTENANCE:

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the glass and surface of the fixture.
2. To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the inside glass and interior surface of the fixture.
3. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

LIMITED WARRANTY

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of five (5) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear.

The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor / expense costs involved in the replacement or repair of said product.